

How to create OpenVPN between IR615 and PC

1. Topology



2. Download and install openvpn-install-2.3.4-I001-i686.exe, as follow:

Step 1: Download OpenVPN client

Google	openVPN	🌷 C	ζ				
	全部 图片 视频 新闻 图书 更多	设置 工					
	找到约 7,440,000 条结果 (用时 0.34 秒)						
	OpenVPN - Open Source VPN https://openvpn.net/ ▼ 翻译此页 OpenVPN - The Open Source VPN. Downloads · OpenVPN Community Software · Access Server Overview · On Cloud						
[Downloads - OpenVPN https://openvpn.net/index.php/open-source/downloads.html ▼翻译此页 Windows installer I601 includes updated OpenVPN GUI (11.9.0.0) and easy-rsa (2.3.2). N OpenVPN's bin directory is no longer added to system PATH. While most users will be un this change, you should have a look at vars.bat.sample if you are migrating an old easy-rs easy-rsa installation	ds - OpenVPN vpn.net/index.php/open-source/downloads.html ▼翻译此页 taller I601 includes updated OpenVPN GUI (11.9.0.0) and easy-rsa (2.3.2). Note that bin directory is no longer added to system PATH. While most users will be unaffected by you should have a look at vars.bat.sample if you are migrating an old easy-rsa CA to a new allotion					
	OpenVPN 2.4 · FAQ · Of /downloads/releases · Graphical User Interface	@51CT()博客				



Step 2: Setup





3. Create CA files:

For this part, please refer to document "Quick Guide for Creating OpenVPN CA files Base on Windows".

4. Sever side configuration

System	Network	Services	Firewall	QoS	N
					Оре
Enable					
Mode		Server •			
Protocol		UDP 🔻			
Port		1194			
Authentication	п Туре	X.509 Cert(r	multiclient) 🔻]	
Pre-shared Ke	у				
Client Subnet		172.16.0.0			
Client Netmas	k	255.255.255	.0		
Remote Subne	et				
Remote Netm	ask	255.255.255	.0		
Link Detection	Interval	60		Seconds	
Link Detection	Timeout	300		Seconds	
Renegotiate Ir	nterval	86400		Seconds	
Enable NAT					
Enable LZO					
Encryption Alg	gorithms	Blowfish(128	8) 🔻		
MTU		1500			



← → C ③ 不安全 192.168.2.1/index.jsp							
nhand	InHan	d No	etv	vorks			
System	Network	Servic	es	Firewall	QoS	VPN	Tools
Certificate Ma	anagement					Certificate Mar	agement
Enable SCEP Certificate En Protocol)	(Simple prollment						
Protect Key							
Protect Key Confirm							
选择文件 ca	.crt		Ir	mport CA Certi	ficate	Export CA Cer	tificate
选择文件未选择任何文件			Import CRL		Export CRL		
选择文件 public.crt			Import Public Key Certificate		Export Public Key Certificate		
选择文件 private.key			Import Private Key Certificate		Export Private Key Certificate		
选择文件未选择任何文件			Import PKCS12		Export PKCS12		
Apply	Cancel						

5. PC side configuration

Step 1: set the client side's configuration :

Specify that we are a client and that we# will be pulling certain config file directives# from the server.client

Use the same setting as you are using on
the server.
On most systems, the VPN will not function
unless you partially or fully disable
the firewall for the TUN/TAP interface.
;dev tap
dev tun



Windows needs the TAP-Win32 adapter name
from the Network Connections panel
if you have more than one. On XP SP2,
you may need to disable the firewall
for the TAP adapter.
;dev-node MyTap

Are we connecting to a TCP or # UDP server? Use the same setting as # on the server. ;proto tcp proto udp

The hostname/IP and port of the server.# You can have multiple remote entries# to load balance between the servers.remote 10.5.11.75 1194;remote my-server-2 1194

Choose a random host from the remote# list for load-balancing. Otherwise# try hosts in the order specified.;remote-random

Keep trying indefinitely to resolve the# host name of the OpenVPN server. Very useful# on machines which are not permanently connected# to the internet such as laptops.resolv-retry infinite

Most clients don't need to bind to# a specific local port number.nobind

Downgrade privileges after initialization (non-Windows only);user inhand;group inhand

Try to preserve some state across restarts. persist-key persist-tun



If you are connecting through an # HTTP proxy to reach the actual OpenVPN # server, put the proxy server/IP and # port number here. See the man page # if your proxy server requires # authentication. ;http-proxy-retry # retry on connection failures ;http-proxy [proxy server] [proxy port #]

Wireless networks often produce a lot# of duplicate packets. Set this flag# to silence duplicate packet warnings.;mute-replay-warnings

SSL/TLS parms.
See the server config file for more
description. It's best to use
a separate .crt/.key file pair
for each client. A single ca
file can be used for all clients.
ca ca.crt
cert client.crt
key client.key

Verify server certificate by checking
that the certicate has the nsCertType
field set to "server". This is an
important precaution to protect against
a potential attack discussed here:
http://openvpn.net/howto.html#mitm
#
To use this feature, you will need to generate
your server certificates with the nsCertType

your server certificates with the nsCertType# field set to "server". The build-key-server# script in the easy-rsa folder will do this.ns-cert-type server

If a tls-auth key is used on the server # then every client must also have the key. ;tls-auth ta.key 1



Select a cryptographic cipher.# If the cipher option is used on the server# then you must also specify it here.;cipher x

Enable compression on the VPN link.# Don't enable this unless it is also# enabled in the server config file.;comp-lzo

Set log file verbosity. verb 3

Silence repeating messages ;mute 20

Step 2: Add the ca files under the config directory:

Windows (C:) > Program Files (x86) > OpenVPN > config					
^	名称 ^	修改日期	类型		
	🔄 ca.crt	2014/7/11 10:51	安全证书		
	🔄 client.crt	2014/7/11 10:51	安全证书		
*	📄 client.key	2014/7/11 10:51	KEY 文件		
*	Ω client.ovpn	2018/1/25 15:21	OpenVPN Confi		
*	README.txt	2018/1/25 12:02	文本文档		

6. Double-click OpenVPN GUI to run this client.

