

InRouter 600

APPLICATION GUIDE FOR TRIGGERED BY SMS

Version: V1.0 Date: 2019.03

InHand Networks Global Leader in Industrial IoT

Contents

2. Configuration	1. Abstract	1
3. Test and Verify	2. Configuration	1
	3. Test and Verify	3

1. Abstract

This guide shows how to configure IR600 accessing to the Internet triggered by SMS. It is used to control the router dialup connected or not. With SMS triggering, the administrator can change the dialup status at any time and anywhere.



As the above figure shows, after receiving the SMS connected command, the router starts to dialup. When the user sends disconnected command by SMS, the router will stop the dialup correspondingly.

2. Configuration

Before doing the configuration, please make sure the SIM card is active and the phone number is known.

2.1 Click Netwoks \rightarrow Dialup, enable Dialup

Network	Serv	System	Network	Services	Firewall	QoS	VPN	Tools	Application	Status
Dialup					Your	password have	security ris	<, please click	here to change	!
WAN		Fnable					Dialup			
Link Backup		Time sched	ule	ALL	 Schedul 	e Management				
LAN		Shared Con Default Rou	nection(NAT) Ite	s						
Switch WLA Mode	N	Network Pro Network Se Connection	ovider (ISP) lect Type Mode	China Uni Auto	com(FDD-LTE) • On Demand •)	▼ Mai	nage		
WLAN		Triggered	by SMS							
IP Passthrou	ıgh	SMS Conn SMS Disco	ect Command onnect Command	ABC QSC		(English Only) (English Only)				
DNS		Max Idle T Redial Inter	'ime val	30 30	Seconds Seconds					
DDNS		Show Adva	nced Options		1					
Static Route		Appl	y Cancel							

2.2 Select your Network Provider (ISP)

China Unicom(FDD-LTE)
Custom
China Mobile (GPRS/EDGE)
China Mobile (Public Beijing APN for GPRS/EDGE)
China Mobile (TD-SCDMA)
China Mobile (TD-LTE)
Vodafone UK
Verizon 4G
Verizon LTE
Airtel-Vodafone
China Telecom(CDMA)
China Telecom(CDMA/EVDO)
China Telecom(EVDO)
China Telecom(FDD-LTE)
China Unicom(HSUPA)
China Unicom(FDD-LTE)

If there is no suitable choice for you, please select Custom.

Network Provider (ISP)	Custom	T	Manage
APN	uninet		
Access Number	*99***1#		
Username	gprs		
Password	••••		

Then, fill in the corresponding information of your SIM card.

2.3 Select Connection Mode as Connect On Demand.

Connection Mode	Connect On Demand 🔻	
Triggered by SMS	Always Online	
inggered by sivis	Connect On Demand	
SMS Connect Command	Manual	(English Only)

2.4 Enable Triggered by SMS

2.5 Set both SMS Connect Command and SMS Disconnect Command

Administrator uses these commands to control the router dialup connection. You can set the commands as whatever you want.

2.6 Set Max Idle Time and Redial Interval

Max Idle Time: use to set up the online time of the router. If the value is "0", the router will keep online after receiving the connect command. If not, for example as 600s, the router will online 600s and then dropped.

Redial Interval: the router will redial every 30s if dial up fail.

2.7 Click Apply

3. Test and Verify

3.1 Click Status → Netwok Connections

Status	System	Network	Services	Firewall	QoS	VPN	Tools	Application	Status
System				Your pa	assword hav	e security risl	c, please click	here to change	!
Modem						Network Con	nections		
Traffic Statistics	Dialup								
Alarm	Connection T	1000	Dialup						
WLAN	IP Address	ype	0.0.0.0						
Network Connections	Netmask Gateway		0.0.0.0						
Route Table	DNS		0.0.0.0						
Device List	MTU		1500						
Log	Status	·	Disconnecte	ed					
Third Party Software Notices	Connect Dis	sconnect							

At the beginning, the dialup status shows **Disconnected**.

3.2 Send the connect command

Send your connect command to the router, e.g. ABC, then wait a few decades seconds. The status will change to **Connected**.

System	Network	Services	Firewall	QoS	VPN	Tools	Application	Status	
			Your pa	assword ha	ve security risk	, please click	here to change!		
Dialun					Network Con	nections			
Diarap									
Connection 7	Туре	Dialup							
IP Address		10.199.5.196							
Netmask		255.255.255.248							
Gateway 10.199.5.193									
DNS		119.6.6.6,2	202.102.128.68						
MTU		1500							
Status		Connecte	b						
Connection time 0 day,		0 day, 00:	00:05						
Connect Di	isconnect								

3.3 Send the disconnect command

Send disconnect command to the router, e.g. QSC, then after a few second the Status will change to **Disconnected** again.

Contact Us

Add: 3900 Jermantown Rd., Suite 150, Fairfax, VA 22030 USA E-mail: support@inhandneworks.com T: +1 (703) 348-2988 URL: www.inhandnetworks.com



InHand Website

© 2019 InHand Networks Inc. All rights reserved.InHand Networks Inc. reserves the right to update or modify, this document at any time without prior notice.