

OS support

Windows XP/Vista/Win7/Win8/Win10 Computer USB port interfaces with the keyboard without needing to install drivers or software.

## **Function Introduction**

There are 8 backlighting effects by press FN+F1: Go with the Cycle breath,
Constantly, Response, Neon, Ambilight, Comet tail, Single water, Flow water.
FN+F2: Change backlight color (Only for Cycle breath, Constantly, Response, Comet tail,
Single water, Flow water mode).
FN+F3: Turn on/off the backlight.
FN+F4: Brightness decreasing (Only for Constantly, Response, Comet tail, Single water,
Flow water mode).
FN+F5: Brightness increasing (Only for Constantly, Response, Comet tail, Single water,
Flow water mode).
FN+F8 Back to factory setting

FN+R: Back to factory setting.
Default setting: G1: My Computer G2: Page Up G3: Page Down

Please download the driver from https://bit.ly/2OnE8xY choose the English version driver to install.

If the keyboard doesn't respond, please check if the keyboards USB cable is correctly inserted into the corresponding USB port on the computer, or try another USB port on the computer.
 If you spill liquid on the keyboard, please remove keyboards USB cable from the computer immediately. Wipe up excess liquid and put the keyboard in a warm place (for instance, under a lamp) to let the keyboard dry naturally before using again.

Download Driver for Windows at:



**f** NPETOfficial

We hope you never have the need, but if you do, our service is friendly and hassle-free.

service@dgnpet.com

Please follow our official YouTube to get more product tutorials videos:






NPET



RGBメンプレン式ゲーミングキーボード片手キーバットグ キーボードの取り扱い説明書





システムサポート

Windows XP/Vista/Win7/Win8/Win10

ドライバが不要、キーボードをコンピューターのUSBポートと接続してから、 すぐ使えます。

## 機能の説明

https://bit.ly/2OnE8xY

FN+F1を押すと、8種のバックライト効果があります。循環呼吸、ずっと点灯、反応、 ネオン、きらきらする星、彗星の尾、単色、流れ。 FN+F2: バックライト色を切り替えます(循環呼吸、ずっと点灯、反応、彗星の尾、 単色、流れのみ)。 FN+F3: バックライトを点灯/消灯します。

FN+F4: 輝度を下げます(ずっと点灯、反応、彗星の尾、単色、流れのみ)。 FN+F5: 輝度を上げます(ずっと点灯、反応、彗星の尾、単色、流れのみ)。

FN+R: 出荷時設定に戻します。 デフォルト設定: G1: マイコンピューター G2: ページアップ G3: ページダウン

マクロの設定方法が何ですか? 以下のURLでドライバをダウンロードし、英語版または日本語版のドライバをインス トールしてください。

よくある質問
1. キーボードを認識できない場合、キーボードのUSBをコンピューターに正しく接続されるかどうかをご確認ください。または、他のUSBボートと接続してみ 接続されるかとフルを一張になってください。

2. キーボードに液体をこぼした場合、すぐにキーボードをコンピューターから取り外してください。余分な液体を拭き取り、キーボードを暖かい場所(たとえば、ランプの下)に置いて、自然に乾かしてから、ご使用ください。

Windows用のドライバをダウンロードする:



何かお問合わせたいと、遠慮しないで、弊店にご連絡ください。弊店はすぐ 丁寧に対応いたします。ご安心ください。

service@dgnpet.com NPETGame JP

より多くの製品チュートリアルビデオを得るために、弊店の公式YouTube に従ってください: https://bit.ly/2CWCldW





NPET YouTube