

# SMS Function on IR900

## 1. Configure SMS on IR900

IR900 support reboot and redial-up/down via SMS. Configuration steps as the following:

(1) Enable SMS function: Network->SMS

Network >> SMS

Basic

Enable

Mode


Poll Interval  s(0: disable)

SMS Access Control

ID	Action	Phone Number
1	permit	18602334534
2	permit	

Add

(2) Text message “reboot” to restart the router as the following:



(3) In the same way, text message “cellular 1 ppp up” to make device redial-up, or text message “cellular 1 ppp down” to make device disconnect ppp connction.

## Contact us

Copyright © 2011 InHand Networks, All rights reserved.

Tel: 86-10-64391099-8022

Address: Wangjing Science Park, Road Lizezhonger,  
Chaoyang District, Beijing, P. R. C, 100102

Website: <http://www.inhandnetworks.com>

Email: [info@inhandnetworks.com](mailto:info@inhandnetworks.com)