How to Register and Update Your Scanner?

The scanner can be updated to keep you stay current with the latest development of diagnosis. This section illustrates how to register and update your scan: i70Pro, i70

To register and update your scanner, please make sure wifi connected, then follow the steps as below:

1. Register the Scanner

You can register and update your scanner on your tablet scanner.

1. Tap the Update icon at the home screen of our diagnostic APP:



Figure 1-1 Sample Update screen

Or or select My Account to access the registration screen.



Figure 1-2 Sample My Account Screen

Enter one of your email addresses as your user ID and click the Send Code button. We will send a 4-digit verification code to the email you just entered.



Figure 1-3 Sample Register Screen

Find the security code in your mailbox, input the code, create a password and click Free Registration to complete.



Figure 1-4 Sample Registration Screen

 A The account has been created successfully message will appear if you registered successfully.



Figure 1-5 Sample Registration Success Screen

When your Foxwell account register successfully the scanner series number will be automatically recognized.



Figure 1-6 Sample Serial Number recognized Screen

 Click Submit to complete your scanner registration, A Product is registered successfully message will appear



Figure 1-7 Sample Registration Success Screen

2. Update the Scanner



To update your scanner please make sure wifi connected.

1. Press the Update application from home screen or press Update shortcuts on the navigation bar, and the update client starts up automatically.



Figure 2-1 Sample Diagnostic App Update Screen

2. The available updates display. Click the check box(s) in front of the software you wish to update and then click the Update button to download.



Figure 2-2 Sample Update Screen

3. When all the items are updated, a "Update Done" message displays.