

Establish IPsec VPN between Cisco and IR900

Configure Cisco Router

Current configuration : 1603 bytes

```

!
crypto isakmp policy 1                                //define IKE Policy
  encr 3des                                           //define 3des cryptographic algorithm
  hash md5                                           //define md5 hashing algorithm
  authentication pre-share                          //define to pre-shared key authentication mode
  group 2                                             //define Diffie-Hellman identifier
crypto isakmp key abc123 address 0.0.0.0 0.0.0.0    //configure pre-shared key to abc123 (according to your need),
                                                    the other side of VPN is 0.0.0.0 (because InRouter's IP is always dynamic IP)
!
!
crypto ipsec transform-set ESP-3DES-MD5 esp-3des esp-md5-hmac //create mapping ensemble esp-3des esp-md5-hmac,
                                                    "ESP-3DES-MD5" is the name of mapping
                                                    ensemble.
!
!
!
crypto dynamic-map DYNMAP 100                        //create dynamic security map DYNMAP 100
  set transform-set ESP-3DES-MD5                    //use the mapping ensemble mentioned above
  ESP-3DES-MD5
  match address 100                                  //quoted the access-list to determine the flow of protected
!
!
crypto map OUTSIDE_MAP 10000 ipsec-isakmp dynamic DYNMAP //put dynamic map into formal map
                                                    "OUTSIDE_MAP" is the name of formal map
!
!
!
!
interface FastEthernet0/0
  ip address 219.239.xxx.xxx 255.255.255.240
  ip nat outside
  duplex auto
  speed auto
  crypto map OUTSIDE_MAP                            //apply confidentiality map to FastEthernet0/0
!

interface FastEthernet0/1
    
```

```

ip address 192.168.1.1 255.255.255.0
ip nat inside
duplex auto
speed auto
!
ip nat inside source list 101 interface FastEthernet0/0 overload //configure NAT, the access from 192.168.1.0/24 to
192.168.2.0/24 is not translated , other access will be translated to IP address on
FastEthernet0/0
ip route 0.0.0.0 0.0.0.0 219.239.xxx.xxx //configure RIP
!
no ip http server
no ip http secure-server
!
access-list 100 permit ip 192.168.1.0 0.0.0.255 192.168.2.0 0.0.0.255 //define VPN protected flow
access-list 101 deny ip 192.168.1.0 0.0.0.255 192.168.2.0 0.0.0.255 //define NAT regulated access-list
access-list 101 permit ip 192.168.1.0 0.0.0.255 any
!
end

```

Configure IR900

1. Click “Wizard” to create a new IPsec Tunnel:

The screenshot shows the InHand network management interface. On the left is a navigation menu with categories: Administration, Layer2 Switch, Network, Link Backup, Routing, Firewall, QoS, VPN, Industrial, Tools, and Wizards. The 'Wizards' menu item is highlighted with a red box. The main content area is titled 'Wizards >> New IPsec Tunnel' and has two tabs: 'Status' and 'Basic Setup'. The 'Status' tab is active, displaying 'System Status' information for a Router (IR915P). Below the status information is a list of wizard options: 'New LAN', 'New WAN', 'New Cellular', 'New IPsec Tunnel' (highlighted with a red box), and 'IPsec Expert Config'. A 'Sync Time' button is also visible.

System Status	
Name	Router
Model	IR915P
Serial Number	RP9151406232931
MAC Address	0018.0505.9bb1
	0018.0505.9bb2
Current Version	1.0.0.r8618
Current Bootloader Version	2011.09.r5656
Router Time	2016-11-15 11:19:31
	2016-11-15 11:18:15 Sync Time
New LAN	
New WAN	0 day, 00:01:16
New Cellular	0.19 / 0.08 / 0.03 (5 mins)
New IPsec Tunnel	120.18MB / 71.45MB (59.46%)
IPsec Expert Config	

Wizards >> New IPsec Tunnel

New IPsec Tunnel

<ul style="list-style-type: none"> Administration > Layer2 Switch > Network > Link Backup > Routing > Firewall > QoS > VPN > Industrial > Tools > Wizards > <p style="text-align: center; margin-top: 20px;"><u>Save Configuration</u></p> <p style="font-size: small; margin-top: 20px;">Copyright ©2001-2016 InHand Networks Co., Ltd. All rights reserved.</p>	<div style="border: 1px solid black; padding: 10px;"> <p>Basic Parameters</p> <p>Tunnel ID <input style="width: 50px;" type="text" value="1"/></p> <p>Map Interface <input style="width: 100px;" type="text" value="cellular 1"/></p> <p>Destination Address <input style="width: 150px;" type="text" value="203.86.63.238"/></p> <p>Negotiation Mode <input style="width: 100px;" type="text" value="Main Mode"/></p> <p>Local Subnet <input style="width: 100px;" type="text" value="192.168.2.1"/></p> <p>Local Netmask <input style="width: 100px;" type="text" value="255.255.255.0"/></p> <p>Remote Subnet <input style="width: 100px;" type="text" value="192.168.11.1"/></p> <p>Remote Netmask <input style="width: 100px;" type="text" value="255.255.255.0"/></p> <p>Phase 1 Parameters</p> <p>IKE Policy <input style="width: 100px;" type="text" value="3DES-MD5-DH2"/></p> <p>IKE Lifetime <input style="width: 100px;" type="text" value="86400"/> s</p> <p>Local ID Type <input style="width: 100px;" type="text" value="IP Address"/></p> <p>Local ID <input style="width: 150px;" type="text"/></p> <p>Remote ID Type <input style="width: 100px;" type="text" value="IP Address"/></p> <p>Remote ID <input style="width: 150px;" type="text"/></p> <p>Authentication Type <input style="width: 100px;" type="text" value="Shared Key"/></p> <p>Key <input style="width: 100px;" type="text" value="....."/></p> <p>Phase 2 Parameters</p> <p>IPSec Policy <input style="width: 100px;" type="text" value="3DES-MD5-96"/></p> <p>IPSec Lifetime <input style="width: 100px;" type="text" value="3600"/> s</p> </div>
---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Basic Parameters: set basic parameters of IPSec tunnel.

Destination Address: set to VPN server IP/domain, e.g.: server IP address is 203.86.63.238

Startup Modes: select Auto Activated.

Negotiation Mode: optional between Main Mode and Aggressive Mode. Generally, select Main Mode.t

Local Subnet: IPSec local subnet protected. E.g.: 192.168.2.1. **It's the InRouter subnet, you can set InRouter LAN address**

Local Net Mask: IPSec local Net Mask protected. E.g.: 255.255.255.0.

Remote Subnet: IPSec remote subnet protected. E.g.: 192.168.11.1. **It's the ZyXel firewall intranet, you can set the subnet which your business server is in.**

Remote Net Mask: IPSec remote Net Mask protected. E.g.: 255.255.0.0.

Phase 1 Parameters: configure parameters during the Phase 1 of IPsec negotiation.

IKE Policy: optional between 3DES-MD5-96 and AES-MD5-96, suggest selecting 3DES-MD5-96.

IKE Lifetime: the default is 86400 seconds.

Local ID Type: optional among FQDN, USERFQDN, IP address, suggest selecting IP address.

Remote ID Type: optional among FQDN, USERFQDN, IP address, suggest selecting IP address.

Authentication Type: optional between Shared Key and Certificate, generally choose Shared Key.

Key: set IPsec VPN negotiating key.

Phase 2 Parameters: configure parameters during the Phase 2 of IPsec negotiation.

IPsec Policy: optional between 3DES-MD5-96 and AES-MD5-96, suggest selecting 3DES-MD5-96.

IPsec Lifetime: the default is 3600 seconds.

2. Click “Apply” to finish adding IPsec Tunnel:

The screenshot shows the InHand VPN configuration interface. The left sidebar contains a navigation menu with items: Administration, Layer2 Switch, Network, Link Backup, Routing, Firewall, QoS, VPN, Industrial, Tools, and Wizards. The main content area is titled 'VPN >> IPsec' and has three tabs: 'Status', 'IPsec Setting', and 'IPsec Extern Setting'. The 'IPsec Setting' tab is active.

Under 'IPsec Setting', there is a table for IPsec policies:

ID	Encryption	Hash	Diffie-Hellman Group	Li fetime
1	3DES	MD5	Group2	86400
<input type="text"/>	AES128	SHA1	Group2	86400

Below this is the 'IKEv2 Policy' section with a similar table:

ID	Encryption	integrity	Diffie-Hellman Group	Li fetime
<input type="text"/>	AES128	SHA1	Group2	86400

Next is the 'IPsec Policy' section with a table:

Name	Encapsulation	Encryption	Authentication	IPsec Mode
ipsecwz1	ESP	3DES	MD5	Tunnel Mode
<input type="text"/>	ESP	AES128	SHA1	Tunnel Mode

At the bottom, the 'IPsec Tunnels' section is highlighted with a red box. It contains a table:

Name	Status	Local Subnets	Remote Subnets	Interface	IKE Version
IPsec2_203.86.63.238	Disconnected	192.168.2.0/255.255.255.0	192.168.11.0/255.255.255.0	fastethernet 0/1	IKEv1

Buttons for 'Add', 'Modify', and 'Delete' are located below the IPsec Tunnels table.

You can check the basic information about this IPsec VPN tunnel as the above picture shows.

Copyright © 2011 InHand Networks, All rights reserved.

Tel: 86-10-64391099-8022

Fax: 86-10-64399872

Address: Wangjing Science Park, Road Lizezhonger, Chaoyang District, Beijing, P. R. C, 100102

Website: <http://www.inhandnetworks.com>

Email: info@inhandnetworks.com

